

Câblage des microphones(source Radio DX Center)

MICRO	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6	PIN 7	PIN 8
ICOM	MICRO	8 volts	UP/DOWN	SQUELCH	TX	MASSE TX	MASSE MICRO	HAUT PARLEUR
KENWOOD	MICRO	TX	DOWN	UP	8 VOLTS		MASSE MICRO	MASSE TX
ALINCO	MICRO	TX	DOWN	UP	8 VOLTS		MASSE MICRO	MASSE TX
YEASU	UP	COMMUN 1&3	DOWN	>5	SCAN RAPIDE	TX	MASSE	MICRO
D.T.N	MICRO		TX	MASSE		UP/DOWN	>MONTEE	RX
PRESIDENT	MICRO	RX	TX	UP/DOWN	MASSE	13 VOLTS		
RCI	MASSE	MICRO	TX	RX	UP	DOWN		
ALAN 28	MICRO	TX	RX	TX	UP/DOWN	>MONTE		
LINCOLN	MICRO	MASSE	TX	UP	DOWN			
SHOGUN	MICRO	MASSE	TX	UP	DOWN			
EURO-CB	MICRO	MASSE	RX	TX	UP/DOWN			
DIRLAND	MICRO	MASSE	RX	TX	UP/DOWN			
PRESIDENT	MICRO	TX	MASSE		RX			
PRESIDENT	MASSE	MICRO	TX	RX				
SUPERSTAR	MASSE	MICRO	TX	RX				
CRT	MASSE	MICRO	TX	RX				
EURO-CB	MICRO	MASSE	RX	TX				
MIDLAND	MICRO	MASSE	RX	TX				
PRESIDENT	MICRO	TX	MASSE					